

Atomic Scale Processing

ALD, ALE & CVD Process Solutions

Atomic Scale Processing

Driving innovation at the atomic scale

Atomic scale processing means wafer-scale processing with control at the atomic scale. This atomic-level control extends to deposition of thin films, removal or etching of material, and growth of 1D and 2D materials.

Fundamental Research and Development Toolkit – Clusterable Atomic Scale Processing Technology

- Atomic Layer Deposition (ALD) of dielectrics & conductive materials with low damage
- Atomic Layer Etch (ALE) of Silicon, GaN & 2D materials
- 1D & 2D materials growth - Chemical Vapour Deposition (CVD) & ALD of atomically thin structures

Example applications

- GaN, SiC and next generation power devices
- Highly conformal, low oxygen content nitrides for quantum applications
- Conformal dielectric coatings for high-K gates, photonics, microfluidics, MEMS
- Graphene and other 2D materials
- Biocompatible layers for medical devices
- Passivation layers for BioMEMS, OLEDs, solar cells
- Electron and hole transport layers in perovskite solar cells
- High aspect ratio diffusion barriers for Cu interconnects
- Storage capacitor dielectrics



Driving innovation at the atomic scale. Clustering multiple processing modules into one system enables unique solutions on a single vacuum transfer.

Atomic Layer Deposition (ALD)


ALD offers precisely controlled ultra-thin films for advanced applications on the nanometre scale.

Oxford Instruments' ALD equipment offers unique capability by combining remote plasma ALD processes with thermal ALD.

The remote plasma option allows for the widest possible choice of precursor chemistry with enhanced film quality.

- Plasma enables low-temperature ALD processes and the remote source maintains low plasma damage
- Eliminates the need for water as a precursor, reducing purge times between ALD cycles
- Higher quality films through improved removal of impurities, leading to lower resistivity conducting layers and higher density insulators


The reactivity of plasma and volatility of the species used allows for short purge times, even at very low sample temperatures.



ALD cycle

—for Al_2O_3 deposited using TMA and O_2 plasma

Key: ● O ● Si ● Al ● H ● CH_3
● CO_2 ● H_2O ● CH_4




ALD Benefits


Conformal, controlled, low pin-hole nanoscale growth

Process benefits:


- High quality films grown with ultimate thickness accuracy, one atomic layer at a time
- Tuneable film properties using RF bias
- Low damage plasma ALD
- Up to 200 mm wafer with typical uniformity $< \pm 2\%$
- Excellent step coverage even inside high aspect ratio structures
- Virtually pin-hole free films
- Low film impurities; particularly with plasma ALD
- Growth at room temperature possible with plasma ALD
- Low resistivity for conductive nitride and metal films by plasma ALD
- Superb thin film barrier properties



High thickness uniformity for standard plasma ALD Al_2O_3 process on 200 mm wafers. Similar uniformities are expected for many of our plasma and thermal ALD processes.



Diffusion barriers with excellent water vapour transmission rates. 20 and 40 nm Al_2O_3 deposited using plasma ALD at room temperature, perform even better than a 300 nm $\alpha\text{-SiN}_x\text{:H}$ deposited by PECVD. Data courtesy of TU/e.



Al_2O_3 , SiO_2 and TiO_2 grown at room temperature. Due to the high reactivity of plasma ALD, many materials can be deposited at lower temperature as compared to when using thermal ALD.

ALD Process

Process library and development

ALD materials list

● Nitrides ● Oxides ● Metals ● Fluorides ● Sulphides

AlN		GaN	HfN				NbN		Si ₃ N ₄		TaN	TiN	WN		
Al ₂ O ₃	Co ₃ O ₄	Ga ₂ O ₃	HfO ₂	In ₂ O ₃	Li ₂ CO ₃	MoO ₃	Nb ₂ O ₅	NiO	SiO ₂	SnO ₂	Ta ₂ O ₅	TiO ₂	WO ₃	ZnO	ZrO ₂
						Pt			AlF ₃	MgF ₂			MoS ₂	WS ₂	

Precursors

Metal precursors

Liquid or solid precursors vapours can be delivered to the reaction chamber by heating up to 200 °C.

Non-metal precursors




H ₂ O	Thermal Oxides
Ozone	Thermal Oxides
O ₂	Plasma oxides, plasma metals, thermal metals
N ₂	Plasma nitrides
H ₂	Plasma metals, plasma nitrides, some thermal metals
NH ₃	Thermal nitrides and some plasma nitrides

Precursor delivery

Delivery modes:

- Multiple liquid or solid precursor delivery systems
- Vapour draw or bubbling up to 200 °C source temperature
- Precise control through fast ALD valves and wide range of plasma gas mixtures possible with independent MFC control of gases

Plasma ALD of 80 nm Al₂O₃ from TMA and O₂ plasma in a 10:1 aspect ratio deep trench capacitor structure.



Atomic Layer Etching (ALE)

ALE is a technique designed to allow the accurate removal of one atomic layer at a time; a level of control unachievable using conventional etching.

As layers become thinner to enable the next generation semiconductor devices there is a need for ever more precise process control to create and manipulate these layers.

The **PlasmaPro® 100** ALE delivers this through specialised hardware including:

- Precise control of gas dose
- Excellent repeatability of low power RF delivery
- Rapid switching enabled by fast PLC

All these combine to enable etching with accuracy at the atomic scale.


Process benefits:

- High accuracy of etched depth
- Ideal for nanoscale layer removal
- Possibility of single atomic layer etch (e.g. for 2D materials)
- Smooth etch surfaces
- High selectivity
- Low damage
- Excellent uniformity
- Minimal aspect ratio dependence



Wide range of materials

Material etched	Dose gas	Etch gas
Si or a-Si	Cl ₂	Ar
MoS ₂	Cl ₂	Ar
SiO ₂	CHF ₃ or C ₄ F ₈	Ar or O ₂
AlGaIn/GaN	Cl ₂ BCl ₃	Ar
AlGaIn/GaN	N ₂ O	BCl ₃
SiC	Cl ₂	Ar

25 nm wide Si trenches etched to 110 nm depth, 150 cycles; HSQ mask still in place.




Smooth Si etch surface after 150 ALE cycles.





ALE Process

Process library and development



AFM images show AlGaN surface roughness reduced by 0.3 nm within 30 cycles.



Graph showing true ALE plateau when etching α -Si, the precise control of the RF power is essential to achieve repeatable ALE.


ALE cycle

1

Dose

Chamber is given a short dose with a chemically reactive species (Cl_2 for GaN, AlGaN or Si).

This forms a layer on the substrate surface.



2

Purge


Excess Cl_2 is pumped away to leave just a layer on the substrate surface.



3

Etch

A small amount of DC bias power is applied causing Ar ion bombardment to remove the top layer and leave a fresh substrate surface.



4

Pump by-products

Pump out step to remove all by-products from the chamber before a fresh dose of Cl_2 is introduced.





Chemical Vapour Deposition (CVD)

CVD systems for growth of nanomaterials


PlasmaPro® 100 Nano is a high temperature CVD/PECVD system tailored for high quality deposition of nanostructured materials and Silicon based thin films.

Features:


- Cold wall design with showerhead based uniform gas delivery
- Plasma options for PECVD and chamber cleans: Parallel Plate (capacitively coupled) or remote plasma (ICP)
- Vacuum load lock for quick sample exchange
- Excellent temperature uniformity
- Optional multiple liquid/solid source delivery systems for growth of MoS_2 , MoSe_2 and other TMDCs
- Variable sample sizes up to maximum 200 mm wafers
- Multiple view ports for diagnostics




CVD of graphene domains growing on copper substrates.



CVD Growth of hBN.



CVD ZnO nanowire growth using DEZn precursors.




Chemical Vapour Deposition (CVD)


CVD systems for growth of nanomaterials

Wide range of materials

	700°C table	800°C table	1200°C table
Thin film process	SiO _x , SiN _x , a-SiC, a-Si, μc-Si, polySi*	SiO _x , SiN _x , a-SiC, a-Si, μc-Si, polySi	SiO _x , SiN _x , a-SiC, a-Si, μc-Si, polySi
1D Nanomaterials	MWNTs, Si, Ge NWs, ZnO NWs	MWNTs, SWNTs*, Si, Ge NWs	MWNTs, SWNTs, Si, Ge NWs
2D Nanomaterials	NA	Nano-crystalline Graphene, Vertical Graphene	Graphene, hBN, MoS ₂ , WS ₂ , Vertical Graphene, Nano-crystalline Graphene





CVD growth of 2D MoS₂.




Dense Carbon Nanotubes grown by PECVD.

Raman shift of CVD of WS₂.




PECVD of vertically aligned graphene.



CVD growth of Silicon nanowires using Au nanoparticle catalysts.

PlasmaPro®100 Nano chamber with capacitively coupled plasma hardware for PECVD processing.



Hardware

Plasma processing systems that provide a complete solution to ASP



PlasmaPro® ASP

- Unique patented plasma source, operating with speed
- Higher deposition rate and low damage ALD
- Cooled/heated vapour and heated bubbler precursors for maximum process flexibility
- Clusterable for vacuum transfer of substrates
- Optional cassette to cassette handling



PlasmaPro® 100 ALE

- Superb etch depth control
- Smooth etch surface
- Low damage process
- Digital/Cyclical etch process
- High selectivity
- Process capability up to 200 mm wafers
- High aspect ratio (HAR) etch process

Inside view of precursor pot for liquid/solid precursors.



PlasmaPro® 100 Nano

- Excellent uniformity
- Options of a 700 °C, 800 °C, or 1200 °C table
- Sample sizes up to 200 mm
- Vacuum load lock—quick sample exchange
- Optional liquid/solid source delivery system for growth of MoS₂ MoSe₂ and other TMDCs

Configuration Options

Systems easily configured for cutting edge production or research

We provide unique cluster capability or stand-alone systems enabling the manipulation of matter with atomic scale precision on a production scale.

- 1 Plasma ALD
- 2 ICP CVD & thermal CVD
- 3 ALE
- 4 Handler






Configurations can be located entirely within the cleanroom or through-the-wall


Cluster options

4-way square handler

6-way hex handler



Ballroom



Through the wall

Worldwide Service

Oxford Instruments is committed to supporting our customers' success. We recognise that this requires world class products complemented by world class support. Our global service force is backed by regional offices, offering rapid support wherever you are in the world.

We can provide:

- Flexible service agreements to meet your needs
- Tailored system training courses
- System upgrades and refurbishments
- Immediate access to genuine spare parts and accessories



For further information please contact your local Oxford Instruments Plasma Technology office.

Email

plasma@oxinst.com

UK

Yatton

+44 (0) 1934 837000

Germany

Wiesbaden

+49 (0) 6122 937 161

India

Mumbai

+91 22 4253 5100

Japan

Tokio

+81 3 5245 3261

PR China

Beijing

+86 10 6518 8160/1/2

Shanghai

+86 21 6132 9688

Singapore

+65 6337 6848

Taiwan

+886 3 5788696

US, Canada & Latin America

Concord, MA

TOLLFREE: +1 800 447 4717

visit plasma.oxinst.com

Oxford Instruments, at Yatton, UK, operates Quality Management Systems approved to the requirements of BS EN ISO 9001. This publication is the copyright of Oxford Instruments plc and provides outline information only, which (unless agreed by the company in writing) may not be used, applied or reproduced for any purpose or form part of any order or contract or regarded as the representation relating to the products or services concerned. Oxford Instruments' policy is one of continued improvement. The company reserves the right to alter without notice the specification, design or conditions of supply of any product or service. Oxford Instruments acknowledges all trademarks and registrations. Certain processes are not offered in a few countries, respecting local patents.

© Oxford Instruments plc, 2019. All rights reserved. Ref: ASP Brochure 2023 Update

OXFORD
INSTRUMENTS

